

## iTRAK 5730

Category	Catalogue-Number	Description
Accessory Kit	2198T-A08	iTRAK 5730 Rail Alignment Tool
Accessory Kit	2198T-A09	iTRAK 5730 Mover Loader Tool
Accessory Kit	2198T-A01	iTRAK 5730 Structural Ring Top
Accessory Kit	2198T-A02	iTRAK 5730 Structural Ring Bottom
Accessory Kit	2198T-AL-SYS-4	iTRAK Lubrication System
Accessory Kit	2198T-AS-CD18	iTRAK 5730 Infield Cover Curve
Accessory Kit	2198T-AS-CA03-U	iTRAK 5730 Infield Cover Straight
Motor Module	2198T-L20-T0303-A00-S2	iTRAK 5730 Motor Module Straight
Motor Module	2198T-L20-T0309-D18-S2	iTRAK 5730 Motor Module Curve
Connectors	2198T-CT-CP	iTRAK Control And Power Connector
Connectors	2198T-CT-P	iTRAK Power Connector
Connectors	2198T-CT	iTRAK Passthrough Connector
Rails	2198T-BE-ST03	iTRAK 5730 Bearing Rail 300mm
Rails	2198T-BE-ST06	iTRAK 5730 Bearing Rail 600mm
Rails	2198T-BE-ST09	iTRAK 5730 Bearing Rail 900mm
Rails	2198T-BE-ED18	iTRAK 5730 Bearing Rail Curve
Movers	2198T-VT0304-E	iTRAK 5730 Assembled Mover
Movers	2198T-N1-0304	iTRAK 5730 Position Magnet N1
Movers	2198T-NN-0304	iTRAK 5730 Position Magnet NN
Movers	2198T-M0304-A000-SS	iTRAK 5730 Motor Magnet for own Mover Design
Movers	2198T-VT0304-E	iTRAK 5730 Assembled Mover